



Fake Hang

Frame Rod

Hang frame rod and picture frames on wall in desired location. Remove picture frames to expose nail or screw. For hanging without a bow, cut 1/2 yard of ribbon for each picture frame. Wrap a 1/2 yard of ribbon around frame rod and back down towards nail or screw, with ends being even. Tape ends to wall close to nail or screw. Hang picture on nail or screw. To add bow cut 1 yard of ribbon and slide behind the 1/2 yard of ribbon taped to the wall, bring ends even and tie a bow.

Wall Button

Hang button and picture frame on wall in desired location. Remove picture frame and expose nail or screw. Cut 1/2 yard or ribbon. Take ribbon over button taping both ends to the right and left of the nail or screw. Hang pictures on nail or screw.

Try the new layering fixture to add dimension to any of your frame groupings!

Frame Grouping Ideas

